The Utilty Vinyl Barn Sash

The Vinyl barn sash is created to match a traditional appearance sash that would incorporate modern vinyl profiles that are easy to maintain for the end user. We started using a traditional profile with 2-3/8" wide stiles and top rail and the traditional wider 3-3/8" bottom rail. We designed our sash so that the glass is installed in the assembly process with the bars to create a fastener free face very clean looking unit.

fig A

fig B

To install:

1. Build frame or re-size your opening ¼" larger than the actual barn sash overall size.

2. Measure completed opening to the inside and then cut two sets of 1" x ½" stops (strips).
   a. One for the inside of the barn sash window.
   b. One for the outside of the barn sash window.

3. Install a 1" x ½" wood window stop (or strip) on the outside of the wall. (See fig A)
4. Install/place the barn sash against the stop tightly (See fig B)

5. Install the inside stops tight against the sash wedging the window in place. (See fig C)

fig C

fig D

6. Finally seal from the outside, and finish the outside wall